

#### What should I do if Instant Mode won't launch?

- When the computer is in Standby mode, pressing the **AV MODE** button launches the **WinDVD** software by default. To launch Instant Mode, turn off or place the computer in Hibernate mode and press the **AV MODE** button.
- If the files required for Instant Mode, which are stored with the hidden attribute in the C drive's **InstantON** folder, are compressed, Instant Mode would not launch. To uncompress the files, follow the steps below:
  - 1 Click **Start** and then **Run....**
  - 2 Enter "C:\InstantON" for **Open** and click **OK**.
  - 3 Click **Folders** on the toolbar.
  - 4 Right-click **InstantON** in the folder list in the left pane and click **Properties**.
  - 5 Click **Advanced** on the **General** tab of the window for changing properties.
  - 6 Click to cancel the **Compress contents to save disk space** check box under **Compress or Encrypt attributes**, click **OK**, and then go to step 12. If this check box is not selected, proceed to step 7.
  - 7 Click to select the **Compress contents to save disk space** check box and click **OK**.
  - 8 Click **Apply** on the window for changing properties.
  - 9 On the confirmation window for attribute changes, click the **Apply changes to this folder only** check box and click **OK**.
  - 10 Once again, click **Advanced** on the **General** tab.
  - 11 Click to cancel the **Compress contents to save disk space** check box under **Compress or Encrypt attributes** and click **OK**.
  - 12 Click **OK** on the window for changing properties.
  - 13 Click **OK** on the confirmation window for attribute changes.

! Running **Disk Cleanup** with the **Compress old files** option selected may compress the files required for Instant Mode. If the files are compressed after running **Disk Cleanup**, follow the above procedure to restore the files.